NB3(4”) Installation Guideline

Model: NB3(4”)

Patent Pending

Substrate Requirements

The **NB3(4”)** fastener must be installed into a solid substrate that meets the project engineer’s specifications.

Approved substrate: Wood

Layout & Predrilling

Mark out **NB3(4”)** fasteners to the desired attachment locations on the already waterproofed or membraned surface.

Predrill marked locations using: ⅜” X 2” long drill bit

Waterproofing-Sealing

- Apply sealant in and around predrilled hole according to roofing manufactures compatibility guideline

Installation & Attachment

- Drive the **NB3(4”)** into the predrilled hole using a 5/16” allen key bit until the flange compresses directly on the waterproofed or membraned surface creating a gasket seal.
- Bolt the attachment into the internal threaded port of the **NB3(4”)** with a ¼”-20 bolt using a hand tool only
- Ensure bolt is fully seated in the port without bottoming out
- **Do not use power tools for final tightening of attachment.**

Need Help?

Nill Building Solutions
631-494-6000
info@nillbuildingsolutions.com
www.nillbuildingsolutions.com